

# NUTRITIVE FACIAL MASK (PAPAYA AND ACEROLA)

CODE 01LP12021901

Dermoprotective, antioxidant, nourishing and moisturizing facial mask with velvety sensory.

**ASSESSA**  
www.assessa.com.br

	TRADE NAME	INCI NAME	%	FUNCTION	SUPPLIER
<b>A</b>	DEIONIZED WATER	Water	qsp	Vehicle	-
	DISSODIUM EDTA	Dissodium EDTA	0.1	Chelator	-
	GLYCERIN	Glycerin	3.0	Umectant	-
<b>B</b>	<b>CARBOGREEN QB</b>	<b>Zea Mays (Corn) Starch (and) Caesalpinia Spinosa Gum (and) Algin</b>	<b>3.0</b>	<b>Velvety Sensory, Dry touch on the skin, Spreadability, Thickener, Viscosity Controller and Film Forming</b>	<b>ASSESSA</b>
<b>C</b>	CETEARYL ALCOHOL	Cetearyl Alcohol	5.0	Thickener	-
	CETEARETH- 20	Ceteareth- 20	1.5	-	-
	BHT	Butylated hydroxytoluene	0.01	Antioxidant	-
<b>D</b>	RED CLAY	Kaolin	4.00	Anti-pollution and detox	-
<b>E</b>	<b>FRULIX ACEROLA</b>	<b>Malpighia Glabra(Acerola) Fruit Extract*</b>	<b>5.0</b>	<b>Antioxidant and dermoprotector</b>	<b>ASSESSA</b>
<b>F</b>	<b>FRULIX MAMÃO(PAPAYA)</b>	<b>Carica Papaya (Papaya) Fruit Extract*</b>	<b>5.0</b>	<b>Moisturizer, Nutritive and Protector</b>	<b>ASSESSA</b>
<b>G</b>	EUXYL PE 9010	Phenoxyethanol and Ethylhexylglycerin	1.0	Preservative	Schulke
<b>H</b>	FRAGRANCE 30108305	Fragrance	0.4	Parfum	Drom

**PROCEDURE:** Add phase A in a recipient and start to stir till dissolution. Add gradually phase B at room temperature with stir, heat till 80 °C. Add phase C in a recipient and heat till 80 °C. When both phases are at 80 °C, add phase C in a mix of phases A+B . Stir for 5 min and start to cool. After 30 °C add phases D, E, F, G and H, respectively, with 5 min between each phase. **pH: 5.5 – 6.5**

\* Consult the different preservative systems available. It is not included in INCI.